





MODELLI - MODELS










Piatto AD HOC - Profilo FLAT

Istruzioni di montaggio - Assembling instructions


1

A02	x	2	x	2	4	6	2	2	2	4	x	2	x
A03	1	1	x	2	4	6	2	2	1	1	2	x	1
A09	x	2	x	2	4	6	2	2	2	2	x	4	x
A11	1	1	x	2	4	6	2	2	1	1	x	2	x




9

A02
A03
A09
A11



10

A02
A03
A09
A11



esempio